

# INSTALLATION INSTRUCTIONS

## 3/4" SOLID HARDWOOD PLANK & STRIP PRODUCTS

### FOR MECHANICALLY FASTENED, STAPLE, NAIL OR CLEAT APPLICATIONS

# Bruce®

**RECOMMENDED CLEANER:** Bruce Dura-Luster® No-Wax Floor Cleaner, Armstrong™ Hardwood & Laminate Floor Cleaner

# Armstrong®

**RECOMMENDED CLEANER:** Armstrong Hardwood & Laminate Floor Cleaner

# ROBBINS®

**RECOMMENDED CLEANER:** ForEver™ Finish Cleaner, Armstrong Hardwood & Laminate Floor Cleaner

## I. GENERAL INFORMATION

### Owner/Installer Responsibility

Beautiful hardwood floors are a product of nature and therefore, not perfect. Our hardwood floors are manufactured in accordance with accepted industry standards, which permit grading deficiencies not to exceed 5%. These grading deficiencies may be of a manufacturing or natural type. When flooring is ordered, 5% must be added to the actual square footage needed for cutting and grading allowance (10% for diagonal installations).

- The owner/installer assumes all responsibility for final inspection of product quality grade, manufacture and factory finish. This inspection of all flooring should be done before installation. The installer must use reasonable selectivity and hold out or cut off pieces with deficiencies, whatever the cause. Should an individual piece be doubtful as to grade, manufacture or factory finish, the installer should not use the piece. If questions of quality arise contact the seller immediately.
- Prior to installation of any hardwood flooring product, the installer must determine that the job-site environment and the sub-surfaces involved meet or exceed all applicable standards. Recommendations of the construction and materials industries as well as local codes must be followed. These instructions recommend that the construction and subfloor be clean, dry, stiff, structurally sound and flat. The manufacturer declines any responsibility for job failure resulting from or associated with subfloor and substrates or job-site environmental deficiencies.
- Use of stain, filler or putty stick for touch-up and appropriate products for correcting subfloor voids is accepted as part of normal installation procedures.

## ATTENTION INSTALLERS



## CAUTION: WOOD DUST

Sawing, sanding and machining wood products can produce wood dust. Airborne wood dust can cause respiratory, eye and skin irritation. The International Agency for Research on Cancer (IARC) has classified wood dust as a nasal carcinogen in humans.

Precautionary Measures: If power tools are used, they should be equipped with a dust collector. If high dust levels are encountered, use an appropriate NIOSH-designated dust mask. Avoid dust contact with eyes and skin.

First Aid Measures in Case of Irritation: In case of irritation, flush eyes or skin with water for at least 15 minutes.

*If you have any technical or installation questions,  
or to request a Material Safety Data Sheet, please call  
1 800 233 3823.*

### IMPORTANT HEALTH NOTICE FOR MINNESOTA RESIDENTS ONLY:

THESE BUILDING MATERIALS EMIT FORMALDEHYDE. EYE, NOSE AND THROAT IRRITATION, HEADACHE, NAUSEA AND A VARIETY OF ASTHMA-LIKE SYMPTOMS, INCLUDING SHORTNESS OF BREATH, HAVE BEEN REPORTED AS A RESULT OF FORMALDEHYDE EXPOSURE. ELDERLY PERSONS AND YOUNG CHILDREN, AS WELL AS ANYONE WITH A HISTORY OF ASTHMA, ALLERGIES OR LUNG PROBLEMS, MAY BE AT GREATER RISK. RESEARCH IS CONTINUING ON THE POSSIBLE LONG-TERM EFFECTS OF EXPOSURE TO FORMALDEHYDE.


REDUCED VENTILATION MAY ALLOW FORMALDEHYDE AND OTHER CONTAMINANTS TO ACCUMULATE IN THE INDOOR AIR. HIGH INDOOR TEMPERATURES AND HUMIDITY RAISE FORMALDEHYDE LEVELS. WHEN A HOME IS TO BE LOCATED IN AREAS SUBJECT TO EXTREME SUMMER TEMPERATURES, AN AIR-CONDITIONING SYSTEM CAN BE USED TO CONTROL INDOOR TEMPERATURE LEVELS. OTHER MEANS OF CONTROLLED MECHANICAL VENTILATION CAN BE USED TO REDUCE LEVELS OF FORMALDEHYDE AND OTHER INDOOR AIR CONTAMINANTS.

IF YOU HAVE ANY QUESTIONS REGARDING THE HEALTH EFFECTS OF FORMALDEHYDE, CONSULT YOUR DOCTOR OR LOCAL HEALTH DEPARTMENT.

## II. PREPARATION

### Storage and Handling

Solid wood flooring should be stored in the environment in which it is expected to perform. Deliver the materials to an environmentally controlled site. The wood subflooring materials must not exceed 13% moisture content. Measure and document the moisture content of both subfloor and wood flooring to determine proper moisture content with a reliable wood moisture meter. The difference between the moisture content of the wood subfloor and the wood flooring must not exceed 4% (3% for plank). Acclimate the wood flooring on or off the job, as necessary, to meet these requirements. Store in a dry place being sure to provide at least a four-inch air space under cartons, which are stored upon "on-grade" concrete floors. Flooring should not be delivered until the building has been closed in with windows and doors in place and until cement work, plastering and all other "wet" work is completed and dry. Concrete should be at least 60 days old.



### Job-Site Conditions

- The building should be closed in with all outside doors and windows in place. All concrete, masonry, framing members, drywall, paint and other "wet" work should be thoroughly dry. The wall coverings should be in place and the painting completed except for the final coat on the base molding. When possible, delay installation of base molding until flooring installation is complete. Basements and crawl spaces must be dry and well ventilated.
- Exterior grading should be complete with surface drainage offering a minimum drop of 3" in 10' (7.6 cm in 3 m) to direct flow of water away from the structure. All gutters and downspouts should be in place.
- Solid flooring may be installed on or above grade level. Do not install in full bathrooms. Installation of a suitable subfloor is required over concrete.

- Crawl spaces must be a minimum of 18" (46 cm) from the ground to underside of joists. A ground cover of 6-20 mil black polyethylene film is essential as a vapor barrier with joints lapped six inches and sealed with moisture resistant tape. The crawl space should have perimeter venting equal to a minimum of 1.5% of the crawl space square footage. These vents should be properly located to foster cross ventilation (Figure 1). Where necessary, local regulations prevail.
- Permanent air conditioning and heating systems should be in place and operational. The installation site should have a consistent room temperature of 60°-75° F (16°-24° C) and humidity of 35-55% for 14 days prior, during and until occupied.




Figure 1

**⚠ WARNING!** EXISTING IN-PLACE RESILIENT FLOOR COVERING AND ASPHALTIC ADHESIVES. DO NOT SAND, DRY SWEEP, DRY SCRAPE, DRILL, SAW, BEADBLAST, OR MECHANICALLY CHIP OR PULVERIZE EXISTING RESILIENT FLOORING, BACKING, LINING FELT, ASPHALTIC "CUTBACK" ADHESIVE, OR OTHER ADHESIVE.

These **existing in-place** products may contain **asbestos fibers** and/or **crystalline silica**.

Avoid creating dust. Inhalation of such dust is a cancer and respiratory tract hazard.

Smoking by individuals exposed to asbestos fibers greatly increases the risk of serious bodily harm.

Unless positively certain that the existing in-place product is a non-asbestos-containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content and may govern removal and disposal of material.

See current edition of the Resilient Floor Covering Institute (RFCI) publication Recommended Work Practices for Removal of Resilient Floor Coverings for instructions on removing all resilient floor covering structures or contact your retailer or Armstrong World Industries, Inc. 1 800 233 3823.

The floor covering or adhesive in this package does NOT contain asbestos.

### Subfloor Conditions

- **CLEAN:** Subfloor must be free of wax, paint, oil, sealers, adhesives and other debris.
- **LEVEL/FLAT:** Within 3/16" in 10' (5 mm in 3 m) and/or 1/8" in 6' (3 mm in 2 m). Sand high areas or joints. If the floor is to be glued down, fill low areas with a latex additive cementitious leveling compound of 3,000-PSI minimum compressive strength such as Armstrong S-194 Patch, Underlayment and Embossing Leveler with S-195 Latex Underlayment Additive. Follow the instructions of the leveling compound manufacturer but make certain that the leveling compounds are completely DRY before beginning installation. When mechanically fastening the floor down, flatten low spots with layers of 15# builders felt, plywood or shims (not leveling compounds). Leveling materials must provide a structurally sound subfloor that does not affect the holding power of the fastener.
- **DRY:** Check and document moisture content of the subfloor with the appropriate moisture test. Install moisture retardant materials if needed or desired. (See plank installation note) Moisture retardant materials must meet minimum perm standards of 3 > 50 ASTM D4869-88, Type I or F.S. UU-B-790a, Type I, Grade D, Style 1a. Most asphalt saturated papers, #15 felt or Grade D kraft paper meet this perm rating. Common brown kraft builder paper and red rosin generally do not qualify as a vapor retarders. Concrete subfloors must be a minimum of 30 days old before testing begins.
- **STRUCTURALLY SOUND:** Nail or screw any areas that are loose or squeak. Wood panels should exhibit an adequate fastening pattern, glued/screwed or nailed as system requires using an acceptable nailing pattern. Typical: 6" (15 cm) along bearing edges and 12" (30.5 cm) along intermediate supports. Flatten any swollen edges as necessary. Replace any water-damaged, swollen or delaminated subflooring or underlayments.

NOTE: Avoid subfloors with excessive vertical movement. Optimum performance of wood floor covering products occurs when there is little horizontal or vertical movement of the subfloor. If the subfloor has excessive vertical movement (deflection) before installation of the flooring it is likely it will do so after installation of the flooring is complete.

### Tools & Accessories Needed

NOTE: IT IS EXTREMELY IMPORTANT TO USE THE PROPER ADAPTERS, FACE PLATES, AND STAPLES OR CLEATS. IMPROPER FASTENERS, MACHINES AND AIR PRESSURE CAN CAUSE SEVERE DAMAGE. THE MANUFACTURER OF THIS FLOORING PRODUCT IS NOT RESPONSIBLE FOR DAMAGE CAUSED BY USE OF IMPROPER TOOLS OR MISUSE.

- Chalk line & chalk
- Hardwood flooring cleaner
- Nail set
- Tape measure
- Hammer
- Electric power saw
- NIOSH-designated dust mask
- Electric drill and bits
- Compressor and hose w/in-line regulator for pneumatic tools
- "Blind" fastening machine for 3/4" (19 mm) flooring (see note below) w/1-1/2" or 2" (4-5 cm) fasteners
- Pneumatic finish nailer with 1-1/2" or 2" (4-5 cm) nails or
- 6-8d finish nails
- Moisture meter (wood, concrete or both)
- Broom
- Hand Saw or Jamb Saw
- Eye Protection
- Transition and wall moldings
- Urethane construction adhesive for floors wider than 4" (10 cm)

\* Use a "Blind" nailing machine designed for installing 3/4" (19 mm) hardwood flooring using staples or cleats. The nailing machine MUST HAVE a protective foot attachment to prevent edge bruising and finish damage. Use one of the following: Stanley Bostitch (multiple models) with MILLFOOTKIT, Powernail (multiple models) with NailerShoe, Primatex (multiple models) with Trak-Edge.



### III. SUBFLOOR/UNDERLAYMENT REQUIREMENTS

**NOTE:** Solid wood flooring can be fastened to most existing flooring products providing the subfloor/underlayment materials meet or exceed the following requirements and the flooring materials can be penetrated with the fastener. Laminated rosin paper or 15# builders felt (tarpaper) acts as a moisture retarder and may be used to reduce movement caused by changes in subfloor moisture, thereby reducing cupping and warping. (This is especially helpful over crawl spaces and basements) In addition, the use of these materials can give the flooring a more solid feeling, reduce sound transfer, prevent noise caused by minor irregularities and debris, and make it easier to slide the wood together across the surface of the subfloor. Craft paper may be used to make installation easier but DOES NOT serve any other purpose.

#### Wood Subfloors and Underlayment

**General:** The wood subflooring materials must not exceed 13% moisture content. Measure moisture content of both subfloor and wood flooring to determine proper moisture content with a reliable wood moisture meter. The difference between the moisture content of the wood subfloor and the wood flooring must not exceed 4% for strip and 3% for plank flooring. When installing parallel to the floor joists it may be necessary to stiffen the subfloor system by installing an additional minimum of 3/8" (9.5 mm) approved underlayment. Applicable standards and recommendations of the construction and materials industries must be met or exceeded.

#### Solid Wood Subfloors

- Minimum 3/4" (19 mm) thick with a maximum width of 6' (15 cm) installed at a 45° angle to the floor joists.
- Group 1 dense softwood (Pine, Larch, Douglas Fir, etc.) No 2 common, Kiln dried with all board ends bearing on joists.

**NOTE:** As flooring manufacturers we are unable to evaluate each *engineered* system. Spacing and spans as well as their engineering methods are the responsibility of the builder, engineer, architect or consumer who is better able to evaluate the expected result based on site-related conditions and performance. The general information provided below describes common, *non-engineered* joist/subfloor systems. *Engineered* flooring systems may allow for wider joist spacing and thinner subflooring materials.

#### Wood Structural Panel Subfloors and Underlayment (*Non-engineered*)

Structural panels/underlayment must be installed sealed side down. When used as a subfloor allow 1/8" (3.2 mm) expansion space between each panel. If spacing is inadequate cut in with circular saw. Do not cut in expansion space on tongue and groove panels.

- **Plywood:** Must be minimum CDX grade (exposure 1) and meet US Voluntary Product Standard PS1-95 performance standard or Canadian performance standard CAN/CSA 0325-0-92. The preferred thickness is 3/4" (19 mm) as a subfloor [minimum 5/8" (16 mm)] or 3/8" (9.5 mm) as underlayment
- **Oriented Strand Board (OSB):** Conforming to US Voluntary Product Standard PS2 or Canadian performance standard CAN/CSA 0325-0-92 construction sheathing. Check underside of panel for codes. When used as a subfloor the panels must be tongue and groove and installed sealed side down. Minimum thickness to be 23/32" (18.3 mm) thick when used as a subfloor or 3/8" (9.5 mm) as underlayment. Some board manufacturers recommendations vary.

#### Concrete (*Requires additional subfloor*)

**NOTE:** We do not recommend solid hardwood flooring be installed directly to concrete without the addition of other subflooring materials to which the flooring can be fastened. Some adhesive manufacturers have had substantial success with direct glue applications using a variety of different adhesives and moisture retardant systems. Follow the adhesive manufacturer's recommendations and check their warranty coverage. We will not be responsible for claims associated with direct glue applications of our solid hardwood flooring products since we neither make nor recommend an adhesive for that purpose.

#### Concrete Moisture Tests

All concrete subfloors should be tested for moisture content. Visual checks may not be reliable. Test several areas, especially near exterior and plumbing walls.

The acceptable test method for subfloor moisture content is:

- **Tramex Concrete Moisture Encounter Meter** (Figure 2)  
Moisture readings should not exceed 4.5 on the upper scale.  
(Figure 2 shows an unacceptable reading of over 4.5).

**Note:** The following tests are required in commercial applications, either or both tests are acceptable

- **Calcium Chloride Test (ASTM F8691).** The maximum moisture transfer must not exceed 3 lbs./1000 sq. ft. in 24 hours with this test.
- **RH Levels in Concrete Using In-situ Probes (ASTM F2170-02)** should not exceed 75%.

"DRY" CONCRETE, AS DEFINED BY THESE TESTS CAN BE WET AT OTHER TIMES OF THE YEAR. THESE TESTS DO NOT GUARANTEE A DRY SLAB. ALL NEW CONSTRUCTION CONCRETE SLABS SHOULD HAVE A MINIMUM OF 6 MIL (10 MIL PREFERRED) POLY FILM MOISTURE BARRIER BETWEEN THE GROUND AND THE CONCRETE.

#### Subfloor Systems

##### Bonded to Concrete

Concrete must be of high compressive strength, 3000 PSI or better. Install a suitable moisture retardant followed by a plywood subfloor with a minimum thickness of 3/4" (19 mm). Allow 1/2" (13 mm) expansion space around all vertical objects and 1/8" between all flooring panels. In general smaller panels [less than 4' x 8' (1.2 x 2.4 m)] oriented at 45 degrees (preferred) offer better results. The panel must be properly attached to the subfloor using a minimum of one fastener per square foot and more if necessary. Use pneumatic or powder actuated fasteners. Do not hand nail the subfloor with concrete nails. Install a moisture retardant barrier with joints lapped 6' (15 cm) and begin installation of flooring using 1-1/2" (4 cm) fasteners.

##### Floating Subfloor

Install a suitable moisture retardant followed by a plywood subfloor with a minimum of 3/8" (9.5 mm) [1/2" (13 mm) preferred]. Allow 1/2" (13 mm) expansion space around all vertical objects and 1/8" between all flooring panels. Install a second layer of plywood of the same thickness at a right angle to the previous panels, offsetting the joints 2' (61 cm). Staple together with staples that will not penetrate the first layer of subfloor with a crown width of 3/8" (9.5 mm) or more. Install a moisture retardant barrier with joints lapped 6' (15 cm) and begin installation of flooring.

##### Screeds/Sleepers

**Note:** Solid wood flooring exceeding 4' (10 cm) in width cannot be installed directly to screeds. Screeds should be installed 8'-16' (20-41 cm) apart in rivers of adhesive at right angles to the flooring to be installed. Do not begin installation until all adhesives are properly cured. Install moisture retardant over the screeds prior to installation of the flooring.

### IV. INSTALLING THE FLOOR

#### General Information for "Blind Fastening" Machines

- Avoid striking the edge of prefinished products with the fastener's mallet. Edge crushing can occur causing unsightly cracks and splinters. Use a protective foot attachment to prevent edge bruising and finish damage.
- Improper adapter plates and air pressure settings can cause severe damage to the wood flooring and reduce performance (Figure 3). Always use an in-line regulator to control air pressure to the machine. Set pressure at 70-75 PSI to begin with and adjust until proper fastener setting occurs.



Figure 3

#### General Installation Tips

- Floor should be installed from several cartons at the same time to ensure good color and shade mixture.
- Be attentive to staggering the ends of boards at least 4'-6" (10-15 cm), when possible, in adjacent rows (Figure 4). This will help ensure a more favorable overall appearance of the floor.
- Spans exceeding 20' (6 m) in wood flooring width in areas of high humidity may require the addition of internal or field expansion. This can be accomplished by using spacers, such as small washers, every 10-20 rows inserted above the tongue and removed after several adjoining rows have been fastened. Do not leave spacers in for more than two hours.
- Preselect and set aside boards that blend best with all floor mounted moldings to assure a uniform final appearance. These boards will be installed adjoining the moldings.
- When installing products of uniform length begin the rows with starter boards cut to various lengths. Avoid staggering the rows uniformly to prevent stair-stepping. Boards cut from the opposite end of the row may be used for the next starter boards.
- Always allow a minimum 3/4" (19 mm) expansion around all vertical obstructions.
- Always use a protective foot on the fastening machine to prevent mallet damage and edge bruising.




Figure 4  
Preferred Alignment

#### NOTE: SPECIAL INSTRUCTIONS FOR PLANK FLOORING

Seasonal distortion (shrinkage/cupping) in wide width flooring [4' (10 cm) and over] may be reduced by gluing the flooring to the subfloor, in addition to the use of mechanical fasteners. The installer should be reminded that adhesives used for this purpose will not perform their function when used in conjunction with a moisture retardant. Glue assisted applications will not be satisfactory without direct contact with the subfloor. The glue should be a premium grade urethane construction adhesive applied in a serpentine pattern to the back of the wood as noted in Figure 5.




Figure 5

#### STEP 1: Doorway and Wall Preparation (*All Installations*)

- Undercut door casings and jams. Remove any existing base, shoe mold or doorway thresholds. These items can be replaced after installation. All door casings and jams should be undercut to avoid difficult scribe cuts (Figure 6).
- Install the moisture retardant (if used) parallel to the flooring. Overlap the rows 6" (15 cm). Overlap (top) should be on the same side as the groove of the flooring so that the wood will slide smoothly into place. Staple the moisture retardant material as necessary to prevent excessive movement.




Figure 6

#### STEP 2: Establish a Starting Point (*All Installations*)

- Installation parallel to the longest wall is recommended for best visual effects; however, the floor should be installed perpendicular to the flooring joists unless subfloor has been reinforced to reduce subfloor sagging.
- When possible, always begin layout or installation from the straightest wall, generally an outside wall.
- In at least two places at least 18' (46 cm) from the corner, measure out equal distance from the starting wall (Figure 7) the face width of the starter board plus 1" (2.5 cm) (do not include the width of the tongue in this measurement). Mark these points and snap a chalk line through them. This measurement allows for the required 3/4" (19 mm) expansion and the width of the tongue.




Figure 7

#### STEP 3: Installing First and Second Rows (*Starting from Wall*)

- Use the longest, straightest boards available for the first two rows. For random and alternate width products, use the widest plank for the first row. Align tongue of first row on chalk line. The groove should be facing the starting wall.
- Use a pneumatic finish nailer to face-nail the groove side 1/2" (13 mm) from the edge at 6" (15 cm) intervals and 1'-3" (2.5-7.6 cm) from each end. Then, blind nail using finishing gun held at a 45° angle nail down through the nailing "pocket" on top of the tongue every 6'-8" (15-20 cm) (Figure 8).
- If using finish nails, pre-drill the nail holes with a 1/32" (1 mm) bit approximately 1/2" (13 mm) from back (groove) edge, 1'-3" (2.5-7.6 cm) from each end, and at 6" (15 cm) intervals. Pre-drill at the same intervals at a 45° angle down through the nailing "pocket" on top of the tongue. Face-nail the groove side where pre-drilled. When complete blind-nail at a 45° angle through the tongue of the first row. Fasten using 6 or 8d finish nails. Countersink nails to ensure flush engagement of groove. Avoid bruising the wood by using a nail set to countersink the nails.
- Continue blind-nailing using this method with following rows until blind nailer can be used.




Figure 8

#### STEP 2 - 3 Alternative: Installing First & Second Rows (*Starting from Center*)

- Snap a chalk line down the center of the room.
- Install a sacrificial row that extends the entire length of the room on the centerline.
- Install three rows of flooring.
- Remove the sacrificial row and insert wood glue in the groove followed by a slip tongue (spline) in the exposed groove.
- Always glue and nail the slip tongue in place.
- Installation can now continue from the center in both directions.

#### STEP 4: Dry Lay (Racking) the Floor

- "Dry" lay (rack) materials to cover approximately 2/3 of the room. Begin dry laying (racking) approximately 6" (15 cm) from the edge of the previously installed rows. Avoid pulling boards too tightly together on the sides, as they must move freely when fastening begins.
- Do not cut final board until row has been installed. Cutting the board in advance may result in a board that is too short.
- Visually inspect flooring, setting aside boards that need to have natural character flaws cut out.
- Use these boards for starting and finishing row after objectionable characteristics have been removed.

#### STEP 5: Installing the Floor

- Make certain that you use the pre-matched wood and molding sets at their appropriate locations
- Use the blind nailer to fasten a sacrificial board to the floor. Check for surface damage, air pressure setting, tongue damage, etc. before proceeding. Make all adjustments and corrections before installation begins. Once proper adjustments have been made, remove and destroy the board.
- Begin installation with several rows at a time, fastening each board with at least two fasteners 1'-3" (2.5-7.5 cm) from the ends. Use the fastener schedule (Figure 9) for proper spacing based on board width. End-joints of adjacent rows should be staggered 4'-6" (10-15 cm) when possible to ensure a more favorable overall appearance.

- The last 1-2 rows will need to be face-nailed where clearance does not permit blind nailing with stapler or brad nailer. Pre-drill and face-nail on the tongue side following the nailing pattern used for the first row.
- Rip final row to fit and face-nail. If the final row is less than 1" (2.5 cm) in width, it should first be glued to the previous UNINSTALLED row and the two joined units should be face nailed as one.

Width of flooring	1'-1/2" to 3'-1/2" (4-9 cm)	4' (10 cm) and over
Maximum spacing	10'-12" (25-30.5 cm)	8'-10" (20-25 cm)
Preferred spacing	8'-10" (20-25 cm)	6'-8" (15-20 cm)

#### Fastener Schedule

#### STEP 6: Complete the Installation

- Clean floor with the recommended wood flooring cleaner.
- Install or re-install any transition pieces that may be needed, such as Reducer Strips, T-moldings, or Thresholds. The products are available prefinished to blend with your flooring. (See below)
- Install or re-install all bases and/or quarter round moldings. Nail moldings into the wall, not the floor. Inspect the floor, filling all minor gaps with the appropriate blended filler.
- If the floor is to be covered, use a breathable material such as cardboard. Do not cover with plastic.
- Leave warranty and floor care information with the owner. Advise them of the product name and code number of the flooring they purchased.
- To prevent surface damage avoid rolling heavy furniture and appliances on the floor. Use plywood, hardboard or appliance lifts if necessary. Use protective castors/castor cups or felt pads on the legs of furniture to prevent damage to the flooring.

#### V. TRANSITION AND WALL MOLDINGS

- **Reducer Strip:** A teardrop shaped molding used around fireplaces, doorways, as a room divider, or as a transition between wood flooring and adjacent thinner floor coverings. Fasten down with adhesive, small nails or double-faced tape.
- **Threshold:** A molding undercut for use against sliding door tracks, fireplaces, carpet, ceramic tile, or existing thresholds to allow for expansion space and to provide a smooth transition in height difference. Fasten to subfloor with adhesive and/or nails through the heel. Pre-drill nail holes to prevent splitting.
- **Stair Nosing:** A molding undercut for use as a stair landings trim, elevated floor perimeters, and stair steps. Fasten down firmly with adhesive and nails or screws. Pre-drill nail holes to prevent splitting.
- **Quarter Round:** A molding used to cover expansion space next to baseboards, case goods, and stair steps. Pre-drill and nail to the vertical surface, not into the floor.
- **Combination Base and Shoe:** A molding used when a base is desired. Used to cover expansion space between the floor and the wall. Pre-drill and nail into the wall, not the floor.
- **T-Molding:** A molding used as a transition piece from one flooring to another of similar height or to gain expansion spaces. Fasten at the heel in the center of the molding. Additional rigid support may need to be added to the heel of the molding dependent upon the thickness of the goods covered. Do not use this molding as a transition to carpet.



Reducer Strip



Threshold



Stair Nosing



Quarter Round



T-Molding

#### INSTALLERS - ADVISE YOUR CUSTOMER OF THE FOLLOWING

##### Seasons: Heating and Non-Heating

Recognizing that wood floor dimensions will be slightly affected by varying levels of humidity within your building, care should be taken to control humidity levels within the 35-55% range. To protect your investment and to assure that your floors provide lasting satisfaction, we have provided our recommendations below.

- **Heating Season (Dry)** - A humidifier is recommended to prevent excessive shrinkage in wood floors due to low humidity levels. Wood stoves and electric heat tend to create very dry conditions.
- **Non-Heating Season (Humid, Wet)** - Proper humidity levels can be maintained by use of an air conditioner, dehumidifier, or by turning on your heating system periodically during the summer months. Avoid excessive exposure to water from tracking during periods of inclement weather. Do not obstruct in any way the expansion joint around the perimeter of your floor.

NOTE: Final inspection by the end-user should occur from a standing position.

##### Floor Repair

Minor damage can be repaired with a touch-up kit or filler. Major damage will require board replacement, which can be done by a professional floor installer.